

Determining speed of sound through Doppler's Effect

Abhishek Dasgupta (06MS07)

Indian Institute of Science Education and Research, Kolkata

April 30, 2007

Outline

- ▶ Measure speed of sound.

Outline

- ▶ Measure speed of sound.
- ▶ A buzzer moves on circumferential path.
- ▶ Receiver records sound.

Outline

- ▶ Measure speed of sound.
- ▶ A buzzer moves on circumferential path.
- ▶ Receiver records sound.
- ▶ Sound analysed; frequency shift measured; velocity of sound calculated.

Apparatus

Required

A buzzer, a recorder and an analyzer (in our experiment, it was my laptop), a bicycle wheel, three 1.5 V batteries.

Picture



Theory

- Doppler shift:

$$f' = \left(\frac{v - v_o}{v - v_s} \right) f$$

Theory

- ▶ Doppler shift:

$$f' = \left(\frac{v - v_o}{v - v_s} \right) f$$

- ▶ This is for sound waves, **not** light waves.
- ▶ Here $v_o = 0$. Observer is the laptop.
- ▶

$$f' = \left(\frac{v}{v - v_s \cos \theta} \right) f$$
$$\Rightarrow \frac{f}{f'} = 1 - \frac{v_s \cos \theta}{v}$$

Theory *contd.*

Two extremes. (Buzzer moving away; Buzzer direct approach)

$$\frac{f}{f_1} = 1 - \frac{v_s}{v}$$

$$\frac{f}{f_2} = 1 + \frac{v_s}{v}$$

Subtract:

$$f \left(\frac{1}{f_2} - \frac{1}{f_1} \right) = \frac{2v_s}{v}$$


Procedure

- ▶ Buzzer mounted on the wheel. DC Motor used to rotate it.
- ▶ Speed of buzzer estimated (5.17 m/s). Radius of wheel 0.32 m .

Procedure


- ▶ Buzzer mounted on the wheel. DC Motor used to rotate it.
- ▶ Speed of buzzer estimated (5.17 m/s). Radius of wheel 0.32 m .
- ▶ Two sound recordings taken:
 - ▶ static condition.
 - ▶ while the buzzer is moving.
- ▶ FFT of waveforms done, and frequencies detected.

Static




Frequency of buzzer: 5220 Hz. (play sound)

Moving



Two peaks very closely spaced.

Moving



Two peaks very closely spaced. 5129 Hz and 5290 Hz.
These are our f_1 and f_2 . (play sound)

Results

Working formula:

$$f \left(\frac{1}{f_2} - \frac{1}{f_1} \right) = \frac{2v_s}{v}$$

Plugging in the values, we get:

Results

Working formula:

$$f \left(\frac{1}{f_2} - \frac{1}{f_1} \right) = \frac{2v_s}{v}$$

Plugging in the values, we get:

$$v = 333.8 \text{ m/s}$$

Results

Working formula:

$$f \left(\frac{1}{f_2} - \frac{1}{f_1} \right) = \frac{2v_s}{v}$$

Plugging in the values, we get:

$$v = 333.8 \text{ m/s}$$

Agrees well with expected value of $v \sim 330 \text{ m/s}$.

Endnote

Precautions, Pitfalls

- ▶ Original plan: use condensor microphone and PHOENIX. Use the CRO program to analyze.
- ▶ failed: Condensor microphone not sensitive enough.

Endnote

Precautions, Pitfalls

- ▶ Original plan: use condensor microphone and PHOENIX. Use the CRO program to analyze.
- ▶ failed: Condensor microphone not sensitive enough.
- ▶ Next plan: Condensor microphone output fed to digital storage oscilloscope.
- ▶ failed: Waveform change detected, but frequency reported showed no change between static and moving conditions.

Endnote

Precautions, Pitfalls

- ▶ Original plan: use condensor microphone and PHOENIX. Use the CRO program to analyze.
- ▶ failed: Condensor microphone not sensitive enough.
- ▶ Next plan: Condensor microphone output fed to digital storage oscilloscope.
- ▶ failed: Waveform change detected, but frequency reported showed no change between static and moving conditions.

Precautions

- ▶ Constant frequency buzzer; our buzzer's frequency varied a bit.
- ▶ The receiver should be sensitive enough.
- ▶ Sufficient detail in waveform, for accurate FFT.
- ▶ Sound input within allowable range of the microphone used, or we'll get cutoff.

Endnote

Applications and other things

Other things

- ▶ Verify speed of sound using some other experiment.
(resonance in air column).
- ▶ Turn the experiment around; use the speed of sound to find velocity of source.

Endnote

Applications and other things

Other things

- ▶ Verify speed of sound using some other experiment. (resonance in air column).
- ▶ Turn the experiment around; use the speed of sound to find velocity of source.

Applications

- ▶ Measure velocity of train from frequency shift of whistle.
- ▶ Light version of Doppler: Extensively used to determine speed of galactic objects.

Acknowledgements

My heartfelt thanks to Dr. Swapan Kumar Datta, who helped me at every stage of the experiment, including giving ideas on how to setup the apparatus, and on the procedure itself. Without his help, this experiment would not have been possible.

I thank my other physics teachers, Dr. Ananda Dasgupta , Dr. Somdatta Bhattacharya and Dr. Ranjan Bhattacharya, all of whom guided me and gave me useful tips to improve the experiment. I also thank Mr. Subhas Malo, for helping me in every step of the experiment.

Lastly, I thank our Director, Dr. Sushanta Dattagupta, for giving us this opportunity to express ourselves.

References

1. H.C. Verma, Concepts of Physics, Bharati Bhawan, pp 342-344.
2. http://en.wikipedia.org/wiki/Doppler_effect